


12x6ft DOG KENNEL

PRESSURE TREATED TANALISED TIMBER

DELIVERED FLAT PACKED
EASY TO INSTALL SECTIONS...



Pressure Treated
Tanalised Timber for
Longer Lasting Life!



ASSEMBLY MANUAL


Version 1.1




Order Supplied with:
• 4.0 x 70mm
• 4.0 x 38mm
Easy Drill Screws

Kennel with Run Area

Requires a minimum build area.*
Please see details below.



*Actual finished dimension area 146.1" x 71.3"



STEPS FOR
DOG KENNEL

16x6ft

REPEAT STEPS:
6 • 10 • 13

x1

STEPS FOR
DOG KENNEL

20x6ft

REPEAT STEPS:
6 • 10 • 13

x2

Ready to Build Dog Kennel

Contents & Check List

1X Kennel Floor



Page 3

1X Side Block (69.5")



Page 3

5X Side Block (12")

12x6ft Dog Kennel

3X Back Panels



Page 4, 5 & 6

1X Left Side Panel



Page 4

1X Right Side Panel



Page 6

1X Pop Hole




Page 6

1X Front Left Panel



Page 7

1X Front Middle Panel



Page 7

1X Front Right Panel



Page 7

3X 4ft Kennel Roof



Page 8 & 9

8X Corner Strips



Page 10

3X Roof Felt Sheets



Page 10

6X Felt Strips (4ft)

2X Felt Strips (6ft)

2X Diamond Cap



Page 11

16x6ft Dog Kennel

Requires additional:

1X Back Panel

1X Front Middle Panel

1X Roof Panel

20x6ft Dog Kennel

Requires additional:

2X Back Panels

2X Front Middle Panels

2X Roof Panels



2 Persons Required

Thank you for purchasing your Dog Kennel from us.

All of our Kennels are made from only the finest selected timber which are (Tanalised), specially pressure treated for a longer and lasting durable life span to the elements.

Tools Required to Assemble:



HAMMER



DRILL DRIVER





STANLEY KNIFE



HAND SAW

16x6ft Dog Kennel
REPEAT STEPS:
6 • 10 • 13



20x6ft Dog Kennel
REPEAT STEPS:
6 • 10 • 13

Each Kennel is carefully prepared in sections. Making the assembly process as easy as possible for you. Please follow our simple step-by-step guide and have your dogs new home built in no time!

DELIVERED FLAT PACKED
EASY TO INSTALL SECTIONS...



Pressure Treated Timber

PLEASE NOTE: Use extreme caution when using any tools. Always wear safety gear where necessary. It is advisable that at least 2 or more persons assemble the kennel for health and safety purpose. We are not responsible for any injuries caused whilst assembling this kennel.

STEP • 1

SET THE KENNEL FOUNDATION

KENNEL FLOOR BASE


Set the base for the kennel floor to build on.

Place floor down into the required position/area.

- 12x6ft Kennel (13x7sqft recommended)
- 16x6ft Kennel (17x7sqft recommended)
- 20x6ft Kennel (21x7sqft recommended)

TIPS & ADVICE: It is always good to position your kennel on a solid foundation.

Slabs or Concrete areas are ideal.



STEP • 2

FLOOR BLOCK x1

ATTACH FLOOR BLOCK



Screw into left of floor side as shown.



FIX SIDE POST TO FLOOR EDGE WITH LARGE SCREWS



69.5" Floor Block (63mm x 38mm)



x3 4.0 x 70mm


• = Drill Points using screws provided as shown

STEP • 3

ATTACH BACK PANEL 1 of 3

Position Back Panel 1

Set within the floor planks, sitting off the rear edge.




DO NOT SCREW DOWN THE PANELS TO FLOOR JUST YET!
Screw only the vertical panels to create a standing frame first, allowing room for adjustments.

STEP • 4


LEFT SIDE PANEL

Position Left Side Panel

Now place the Left Side Panel flush against the Back Panel Post.



x3
4.0x70mm



Set side panel left against back panel post as shown on this image.

● = Drill Points using screws provided as shown



DRILL DRIVER

STEP • 5

ATTACH BACK PANEL 2 of 3




Attach Back Panel 2

Use the 2nd Floor Block which is 12" to raise the back panel height then screw against 1st back panels side.



● = Drill Points using screws provided as shown



Position the 2nd back panel in place as shown on diagram below.

Using the 12" Floor Block Posts elevate the 2nd back panel and screw in sides to secure against the 1st back panel side post as shown here.

The back panel 2 must be the same height as the 1st back panel which is 63mm from the ground.



STEP • 6

ATTACH BACK PANEL 3 of 3




Attach Back Panel 3

Use the Floor Block to raise the 3rd back panel to correct height then screw against 2nd back panel frame.



● = Drill Points using screws provided as shown

Position the 3rd back panel in place as shown on diagram below. Use Floor Blocks to elevate. The back panel must be the same height as the 1st and 2nd back panel which is 63mm from the ground.



Screw sides to secure against the previous back panels post as shown here.

Then move on to step 7.



DOG KENNEL 16x6ft REPEAT STEP: x1

DOG KENNEL 20x6ft REPEAT STEP: x2


STEP • 7

ATTACH RIGHT SIDE PANEL



Attach Right Side Panel

Now attach the Right Side Panel by placing against 3rd back panel side as below.



x3
4.0x70mm

● = Drill Points using screws provided as shown

Secure and strengthen the panels if need be to get a strong framework. You may require support for panels to keep in place.



DRILL DRIVER



Using the 12" Floor Block Posts, elevate the right side panel and screw in sides to secure against the 3rd back panel side post as shown.


STEP • 8

ATTACH POP HOLE



Place Pop Hole Panel


Set within the floor planks sitting flush with front and rear panel edges and floor.



x3
4.0x70mm

Note that the back of the pop hole section should align with the height of the back panel as shown. The framework will meet perfectly with the back panel 1

● = Drill Points using screws provided as shown



Position the pop hole section as shown, sitting firmly against back panel 1 and resting on the kennel floor. Screw the framework from inside against the back panel block to make stable.




DRILL DRIVER

STEP • 9

ATTACH LEFT FRONT PANEL 1 of 3


Left Solid Door Panel

Now set the 1st of the front panels.
Position the solid door panel like below.



x6
4.0 x 70mm

● = Drill Points using screws provided as shown



FRONT LEFT PANEL

DRILL DRIVER



Using the 12" Floor Block Posts, elevate the left front panel and screw in sides to secure against the left side panel and pop hole panel as shown.

STEP • 10

MIDDLE FRONT MESH PANEL 2 of 3


Front Middle Mesh Panel

Now place the front middle mesh panel(s)
alongside the left front panel as shown.



x3
4.0 x 70mm

● = Drill Points using screws provided as shown



FRONT MIDDLE PANEL

DRILL DRIVER

Secure the front middle panel(s) alongside the left panel(s) as shown.

DOG KENNEL **16x6ft** REPEAT STEP: **x1**

DOG KENNEL **20x6ft** REPEAT STEP: **x2**

Using the 12" Floor Block Posts, elevate middle mesh panel and screw in sides of panels as shown.


STEP • 11

ATTACH RIGHT FRONT PANEL 3 of 3



Front Mesh Door Panel

Now place the front mesh door panel in between the front left and right side panels.




x6
4.0 x 70mm



FRONT RIGHT PANEL

● = Drill Points using screws provided as shown



Using the 12" Floor Block Posts, elevate the right front panel and place between the middle front panel and right side panel as shown.

DRILL DRIVER


STEP • 12

PLACE ROOF SECTION 1 of 3




1st Roof Section

Now place the 1st of the 3 roof panels as shown in the diagram below.



Secure roof panels by screwing them down to kennel framework as shown.



ROOF PANEL 1

x4
4.0 x 70mm

● = Drill Points using screws provided as shown


DRILL DRIVER

STEP • 13

PLACE ROOF SECTION 2 of 3


2nd Roof Section

Now place the 2nd roof panel as shown in the diagram below.



x5
4.0 x 70mm

● = Drill Points using screws provided as shown



DRILL DRIVER

DOG KENNEL **16x6ft** REPEAT STEP: **x1**


DOG KENNEL **20x6ft** REPEAT STEP: **x2**

STEP • 14

ROOF SECTION 3 of 3


Final Roof Section

Now place the last roof panel as shown in the diagram below.



x5
4.0 x 70mm

● = Drill Points using screws provided as shown



DRILL DRIVER

Now screw down the roof and the base adjusting where need be to make final structure safe & solid. Also screw down the side blocks under floating panels.

Remember to drill the panels down to the floor at this stage as all the build sections are together now.

Now secure down the roof and the base adjusting where need be to make final structure safe & solid.

STEP • 15



SIDE STRIPS

Attach Corner Strips


Now finish off the panels edges with the corner strips provided.



x8



Now attached the corner/side strips to hide the corners and joins including any exposed framework between the panel sections as shown.



x16
4.0 x 38mm

● = Drill Points using screws provided as shown

DRILL DRIVER

STEP • 16

APPLY ROOF FELT SHEETS x3

40kg Mineral Felt Roof


You will be provided with 3 lengths of roof felt. Start with lower end of roof first.



x3



1st Sheet at rear of roof



Proceed with 1st layer at the rear lowest point of roof, then overlay the other sections in order as shown. This method is to create rain flow towards rear of kennel.



2nd & 3rd Sheets above



Trim edges with 3" overhanging



Fold & tack edges neatly



TACKS PROVIDED

After cutting away the excess felt, neatly fold over the edges and secure each section down by tacking them to the kennel sides. **PROTECT YOUR KENNEL AGAINST THE RAIN & ELEMENTS.**

Carefully check all the panels are fitted well and the kennel is secure and stable.

You are almost done building your kennel!

STANLEY KNIFE

HAMMER

STEP • 17

FINISH OFF WITH FELT STRIPS



Finishing Touches!


To hide the tacked felt edges add the felt strips along the top edge of roof as shown.

x6 (4ft)
x2 (6ft)

*Sections may come longer than required.
Please saw down to size to fit.




x12
4.0 x 38mm



Create a neat and tidy roof finish hiding the rough edges and tacks. Measure the sides for a perfect cut and finish!

Carefully check all the panels are fitted well and the kennel is secure and stable.



● = Drill Points using screws provided as shown

You may use **Optional Diamond Cap** to cover felt strip join



DRILL DRIVER

CONGRATULATIONS - YOUR DONE!

Timber is a naturally grown product and may shrink and warp when dried out, timber is a porous material which can absorb water. Although all of our buildings come pressure treated we strongly advise the building is re-treated with an oil/spirit based treatment inside and out to make the timber water repellent and to preserve the quality and life of the product.

Ready to Build Dog Kennel

Dog Kennel Sizes also Available in 4x4ft to 20x6ft